

## SRS Hardware Storm Stay SA-01

### Package includes:

Left Arm, Right Arm, 8 screws, 2 peg nails

### Installation instructions:

1. Hang storm sash.
2. Attach Catch Plate to stop  $3/32$ " back from outside edge. Catch Plate bottom should be 12" above sill (Fig. 1).
3. Slip Arm (notch will be facing down when arm is extended), into Catch Plate and fasten base plate to sash (Fig. 2). Drive nail into stop at center of Arm, leaving about  $1/2$ " projecting.

### Operation:

To open storm sash, release arm from nail peg, raise and push outward, unit notch in Arm at bent position engages with the Catch Plate.

To lock storm sash in the closed position, slip Arm over peg nail.

Storm sash may be removed from window by opening and slipping Arm out of Catch Plate.

